
Meridian 1

Application Module and Intelligent Peripheral Equipment Module

Diagnostic and Maintenance Guide

Publication number: 553-3211-510
Product release: Meridian Link Release 5/CCR Release 3B
Document status: Standard 1.0
Date: September 1996

© 1996 Northern Telecom
All rights reserved

Printed in the United States of America

Northern Telecom reserves the right to make changes in equipment, design, or components as progress in engineering or manufacturing may warrant.

Meridian 1 and SL-1 are trademarks of Northern Telecom. UNIX is a trademark of AT&T. Motorola is a trademark of the Motorola Corporation. MVME products are trademarked by the Motorola Corporation.
LaserJet is a trademark of Hewlett-Packard. Reflection is a trademark of Walker Richer & Quinn.

Contents

About this guide	vii
References	vii
Chapter 1: Overview	1
Application Module and IPE Module	1
Customer Controlled Routing	2
Meridian Link	2
Meridian 1 utilities	2
Application Module hardware components	4
IPE Module hardware components	11
SMM167	11
IPE Module faceplate	11
Tape drive	13
Disk drive	13
I/O connectors	13
Application Module and IPE Module utilities	14
Logging in	14
The ccrusr function	15
The maint function	15
The mlusr function	15
The trmcnfg function	16
Advanced maintenance	16

Chapter 2: Application Module commands	17
admin—enter a link-related session	20
appconfig—display/modify application configuration	20
appexit—exit software applications	21
applstart—start software applications	21
backconfig—schedule unattended backup	22
backdata—back up data files	27
backfiles—back up selected data files	31
bootconfig—display and modify boot configuration	34
ccrabort—shut down the CCR application	35
ccrmidnight—run midnight routines on system	36
ccrstart—start up the CCR application	37
ccrtraffic—maintain script statistics	37
ccrusr—enter a CCR user session	43
chgpasswd—change user passwords	44
conshare—Meridian 1 console session	45
diskuse—display disk usage statistics	47
editvoice—create/edit voice prompts	47
exit—log out	48
filedelete—delete a file	49
fileverif—verify system files	50
help—list all commands	51
install—load software tape onto the hard disk	52
langconfig—configure CCR logon screen languages	55
mlexit	56
mlstart	56
mlusr—enter a link-related user session	56
portconfig—configure terminals and printers	57
powerdown—safely power down or reboot the module	59
printconfig—configure printers	63
quit—log out	67
resetmodem—reset the modem on the Application Module	67
restart—stop and start the link processes	68
rootpasswd—change the root password	69
rstdata—restore data from backup tape	70
rstfiles—restore a set of files	73

scriptinfo—display a summary of script information	74
showid—display Meridian 1 information	75
startNSE—activate Ethernet LAN support	76
stopNSE—de-activate Ethernet LAN support	77
tapeinfo—display information on a system tape	78
version—display Application Module or IPE Module software version	79
view—display SysLog and link-related files	82
viewlog—display SysLog file	84

Chapter 3: Link maintenance commands	85
Using link maintenance commands	86
Command format	86
Link control commands	91
enable link	91
disable link	91
Link status commands	92
status link	92
get links	92
Link configuration commands	94
display linkctl	94
change linkctl	95
read linkctl	98
save linkctl	99
display link	100
change link	102
save link	112
read link	113
Link statistics command	114
Meridian Link messages	117
Message types	117
Message names	117
Specifying message types in commands	117

Association services commands	118
get associations	118
get directory numbers	119
get resource	120
message statistics	121
filter commands	124
record commands	127
monitor commands	131
traffic commands	135
Link tracing commands	139
trace link	139
trace main	139
untrace link	140
untrace main	140
Link testing commands	143
continuity test	143
loopback test	144
File viewing commands	148
view	148
viewlog	149
Miscellaneous commands	150
exit	150
quit	150
help	150
version	153

Chapter 4: Diagnosing faults	155
Quick reference fault isolation	155
Diagnostic procedure 1: Power fault suspected (Application Module)	156
Diagnostic procedure 2: Power fault suspected (IPE Module)	162
Diagnostic procedures 3 and 4: Card fault suspected Reseating a card	165
Advanced diagnostic tests	167
Diagnostic procedure 4: Card fault suspected	174
Diagnostic procedure 5: System console fault suspected	176
Diagnostic procedure 6: System start-up problem	182
Diagnostic procedure 7: Dial-up problem	185
Diagnostic procedure 8: Application terminal problem	188

Diagnostic procedure 9: Printer faults	198
Disk/tape drive unit faults	204
Login failure	205
Difficulty logging in as ccusr	205
Difficulty logging in as maint	206
Difficulty logging in as mlusr	207
Link failure	208
AML (Link 0) will not establish	208
X.25 host computer link (Link 1) will not establish	215
TCP/IP host computer link (Link 1) will not establish	223
Meridian Mail Link (Link 2) will not establish	224
Meridian Link application malfunction	225
Application registration fails	225
Meridian Link call processing functions fail	228
Meridian Link-based applications do not receive expected messages	231

Chapter 5: Application Module and 235

Messages that appear on the system console	236
System and UNIX messages	236
Application messages	237
maint messages	241
Other messages that appear on the system console	258
Messages that appear in the SysLog file	264
System and UNIX messages	264
Application messages	265
maint messages	278
Bad-event messages	284
Other messages reported in the SysLog file	285

Chapter 6: Link error messages 289

Link maintenance commands fail	289
mlusr error messages	291
Diagnostic tools error messages	296
Stale association	298
Removing a stale mlusr association	298

Chapter 7: CCR log file messages 301

Chapter 8: Recovery/replacement procedures	363
Powerdown and restart procedures	364
Procedure 1: Software powerdown	364
Procedure 2: SBC restart	366
Procedure 3: Hardware powerdown	368
Procedure 4: Power up the Application Module or IPE Module	368
Hardware replacement procedures	369
Procedure 5: Replace the Application Module power supply	369
Procedure 6: Replace the Application Module disk/tape unit	369
Procedure 7: Replace the Application Module MVME147/167 SBC card	370
Procedure 8: Configure the Application Module MVME147 SBC card	371
Procedure 9: Configure the Application Module MVME167 SBC card or the IPE Module	376
Procedure 10: Replace the Application Module	380
Procedure 11: Replace the MVME332XT or MVME332XTS ACC card	381
Procedure 12: Replace the NT6D51 transition card	382
Procedure 13: Remove the Application Module	383
Procedure 14: Replace the Application Module	384
Procedure 15: Remove the IPE Module	385
Procedure 16: Replace the IPE Module	385
Procedure 17: Replace the Application Module MVME712 transition card	386
Procedure 18: Replace or reconfigure the Application Module MVME705B transition card	390
Software reinstallation—initializing the system from tape	392
Procedure 19: Load the operating system tape on an Application Module with an MVME147 card	393
Procedure 20: Load the operating system tape on an IPE Module or an Application Module with an MVME167 card	410

Procedure 21: Reboot and go through setup	429
Procedure 22: Load the application software from tape	439
Procedure 23: Back up configuration files and data files	452
Procedure 24: Restore configuration files and data files from the backup tape	454
Procedure 25: Enable or disable Ethernet LAN support	458

Chapter 9: List of terms **467**

Chapter 10: Index **473**

Figures

Figure 1	Application Module in the AEM—front view	8
Figure 2	Application Module in the AEM—rear view	9
Figure 3	MPDU circuit breaker associations	10
Figure 4	Cassette tape with write protection disabled	23
Figure 5	Inserting tape into tape drive	24
Figure 6	Cassette tape with write protection disabled	27
Figure 7	Inserting tape into tape drive	28
Figure 8	Cassette tape with write protection disabled	31
Figure 9	Inserting tape into tape drive	32
Figure 10	Example of a recording file	128
Figure 11	Link maintenance help command	151
Figure 12	Application Module LED status indicators under normal operation	165
Figure 13	IPE Module status indicators under normal operation	166
Figure 14	Powerdown notification message screen 1	364
Figure 15	Powerdown notification message screen 2	364
Figure 16	Shutdown message screen	365
Figure 17	Powerdown notification message screen 1	366
Figure 18	Powerdown notification message screen 2	366
Figure 19	Shutdown messages	367
Figure 20	System restart messages	371
Figure 21	Start-up interrupt menu	372
Figure 22	Results of disk/tape controller scan	372
Figure 23	Disk/tape controller list after aligning LUNs	373
Figure 24	Autoboot enable prompts	373
Figure 25	SCSI bus reset prompts	373
Figure 26	Environment prompts for firmware revision 2.2	374